

forward voltage drop reading of 0.5V to 0.8V; however, the reverse-voltage drop reading can vary depending on the resistance of other pathways between the probe tips.

- Connect the test leads to the proper terminals as said above to avoid error display. The LCD will display **OL** indicating diode being tested is open or polarity is reversed. The unit of diode is Volt (V), displaying the forward voltage drop readings.
- When diode and continuity testing has been completed, disconnect the connection between the testing leads and the circuit under test, and remove the testing leads away from the input terminals of the Meter.

F. Measuring Frequency and Duty Cycle (See Figure 7)

UT205A is designed with frequency and duty cycle functions, but only frequency for UT206A.

To measure frequency and duty cycle, connect the Meter as follows:

1. UT205A

- Insert the red test lead into the **Hz%** terminal and the black test lead into the **COM** terminal.
- Set the rotary switch to **Hz**; press **Hz%** button to switch between Hz and Duty cycle measurement mode.
- Or set the rotary to ACV or DCV range, then press **Hz%** button to switch into Hz and Duty cycle measurement mode. But the accuracy will have a little difference based on the input frequency and wave.
- Connect the test leads across with the object being measured. The measured frequency value or duty cycle value shows on the display.




Figure 7

2. UT206A

- Insert the red test lead into the **Hz** terminal and the black test lead into the **COM** terminal.
- Set the rotary switch to **Hz**.
- Connect the test leads across with the object being measured. The measured frequency value shows on the display.

Note

- When frequency and duty cycle measurement has been completed, disconnect the connection between the testing leads and the circuit under test, and remove the testing leads away from the input terminals of the Meter.

G. Measuring Temperature (UT206A Only, See Figure 8)

To measure temperature, connect the Meter as follows:

- Insert the red temperature probe into the **°C** terminal and the black temperature probe into the **COM** terminal.
- Set the rotary switch to **°C**.
- Place the temperature probe to the object being measured.

The measured value shows on the display.




Figure 8

Note

- When there is no temperature probe inserted into the terminals, the LCD displays **OL**.
- The included point contact temperature probe can only be used up to 250 °C. For any measurement higher than that, it is necessary to use another type of temperature probe.
- When temperature measurement has been completed, disconnect the connection between the temperature probe and measured object, and remove the temperature probe from the input terminals of the Meter.

Operation of Hold Mode

⚠ Warning

To avoid possibility of electric shock, do not use Hold mode to determine if circuits are without power. The Hold mode will not capture unstable or noisy readings.

The Hold mode is applicable to all measurement functions.

- Press **HOLD** to enter Hold mode; the Meter beeps.
- Press **HOLD** again or turn the rotary switch to exit Hold mode; the Meter beeps.
- In Hold mode, is displayed.

The Use of Relative Value Mode (UT206A only)

The REL mode applies to all measurement functions except frequency and duty cycle. It subtracts a stored value from the present measurement value and displays the result.

For instance, if the stored value is 20.0V and the present measurement value is 22.0V, the reading would be 2.0V. If a new measurement value is equal to the stored value then display 0.0V.

To enter or exit REL mode:

- Use rotary switch to select the measurement function before selecting REL . If measurement function changes manually after REL is selected, the Meter exits the REL mode.
- Press REL to enter REL mode, auto ranging turns off, and the present measurement range is locked and stored as the stored value. All the measurements done after will be automatically subtract this stored value.
- Press REL again to exit REL mode and return to common measurement mode. If you want to enter the auto ranging measurement mode or other ranges, please turn the rotary switch or power off the Meter and start again.

The SELECT Button

It uses for selecting the required measurement function when there is more than one function at one position of the rotary switch.

Turning on the Display Backlight

⚠ Warning

In order to avoid the hazard arising from mistaken readings in insufficient light or poor vision, please use Display Backlight function.

- Press and hold button for over 2 seconds to turn the Display Backlight on.
- Press button again to turn the Display Backlight off, otherwise it will stay on continuously.

Sleep Mode

To preserve battery life, the Meter automatically turns off if you do not turn the rotary switch or press any button for around 15 minutes.

The Meter can be activated by turning the rotary switch or pressing the effective button, it will return to working mode.

General Specifications

- Maximum Voltage between any Terminals and Grounding: 600V rms or 600V DC.
- Maximum Current Measurement: 1000A.
- of Transformer Jaw:
- Maximum Jaw Opening: 40mm.
- Maximum Display: Digital: 3999
- Overload Display: OL
- Range: Auto
- Polarity Display: Negative display: "-"
- Measurement Speed: Updates 3 times/second.
- Temperature: Operating: 0 °C to +40 °C (32 °F to +104 °F).
- Storage: -10 °C to +50 °C (14 °F to +122 °F).
- Relative Humidity: ≤ 75% @ 0 °C to 40 °C ; ≤ 70% @ -10 to 50 °C .
- Altitude: Operating: 2000 m.
- Storage: 10000 m.
- Battery Type: One piece of 9V (NEDA1604 or 6F22 or 006P).
- Low Battery Indication: Display
- Dimensions (HxWxL): 236mm x 97mm x 40mm
- Weight: Approximate 350g (battery included).
- Safety/Compliances: IEC61010 CAT. II 600V / CAT III 300V and Double Insulation.
- Certifications:

Accuracy Specifications

Accuracy: ± (a% reading + b digits), guarantee for 1 year.

Operating temperature: 23 °C ± 5 °C .

Relative humidity: ≤ 75% .

A. AC Current

Range	Resolution	Accuracy	Remarks
400A	0.1A	±(1.5%+5)	Frequency response 50Hz~60Hz. Display RMS value of sine wave (mean value response).
1000A	1A	800A ≥ ±(2%+5)	
		>800A ±(3%+5)	

B. DC Voltage

Range	Resolution	Accuracy	Overload Protection	Remarks
400mV	100µV	±(0.8%+3)	600V DC 600V AC	Input impedance: around 10MΩ.
4V	1mV	±(0.8%+1)		
40V	10mV			
400V	100mV			
600V	1V			

C. AC Voltage

Range	Resolution	Accuracy	Overload Protection	Remarks
4V	1mV	±(1.2%+5)	600V DC 600V AC	Input impedance around 10MΩ. Displays RMS value of sine wave (mean value response). Frequency response: 40Hz ~ 400Hz.
40V	10mV			
400V	100mV			
600V	1V	±(1.5%+5)		

D. Resistance

Range	Resolution	Accuracy	Overload Protection	Remarks
400Ω	0.1Ω	±(1.2%+2)	500V DC or AC	
4kΩ	1Ω	±(1%+2)		
40kΩ	10Ω	±(1%+2)	500V DC or AC	
400kΩ	100Ω			
4MΩ	1kΩ			
40MΩ	10kΩ	±(1.5%+2)		

E. Diode and Continuity Test

Function	Range	Resolution	Overload	Remarks
Diode		1mV	500V DC or AC	Displays the nearest value of forward voltage drop
Continuity		0.1Ω		Buzzer beeps when ≤100Ω

F. Frequency (auto-ranging)

Range	Resolution	Accuracy	Overload Protection	Remarks
10Hz-10MHz	Min 0.001Hz	±(0.1%+3)	500V DC or VAC	Amplitude a: ≤1MHz: 300mV rms ≤a≤30V rms; >1MHz: 600mV rms ≤a≤5V rms

G. Duty Cycle (Model UT205A only)

Range	Resolution	Accuracy	Overload Protection
0.1%-99.9%	0.1%	For reference only	500V DC or AC

H. Temperature (Model UT206A only)

Range	Resolution	Accuracy	Overload Protection
-40°C~0°C	1°C	±(4%+4)	500V DC or AC
1°C~400°C		±(2%+8)	
401°C~1000°C		±(3%+10)	

Maintenance

This section provides basic maintenance information including battery replacement instruction.

⚠ Warning

Do not attempt to repair or service your Meter unless you are qualified to do so and have the relevant calibration, performance test, and service information. To avoid electrical shock or damage to the Meter, do not get water inside the case.

A. General Service

- Periodically wipe the case with a damp cloth and mild detergent. Do not use abrasives or solvents.
- To clean the terminals with cotton bar with detergent, as dirt or moisture in the terminals can affect readings.
- Turn the Meter to **OFF** position when it is not in use.
- Take out the battery when it is not using for a long time.
- Do not use or store the Meter in a place of humidity, high temperature, explosive, inflammable and strong magnetic field.

B. Replacing the Battery (See Figure 9)

⚠ Warning

To avoid false readings, which could lead to possible electric shock or personal injury, replace the battery as soon as the battery indicator "" appears.

Make sure the transformer jaw and the test leads are disconnected from the circuit being tested before opening the case bottom.

Make sure the test leads are removed from the input terminals.

To replace the battery:

- Turn the rotary switch of the Meter to **OFF** position and remove all the connections from the terminals.
- Remove the screw from the battery compartment, and separate the battery compartment from the case bottom.
- Remove the battery from the battery compartment.
- Replace the battery with a new 9V battery (NEDA1604, 6F22 or 006P).
- Rejoin the case bottom and battery compartment, and reinstall the screw.




Figure 9

** END **

Manufacturer:
Uni-Trend Technology (China) Limited
No 6, Gong Ye Bei 1st Road
Songshan Lake National High-Tech Industrial
Development Zone, Dongguan City
Guangdong Province
China
Postal Code: 523 808

Headquarters:
Uni-Trend Group Limited
Rm901, 9/F, Nanyang Plaza
57 Hung To Road
Kwun Tong
Kowloon, Hong Kong
Tel: (852) 2950 9168
Fax: (852) 2950 9303
Email: info@uni-trend.com
http://www.uni-trend.com