

# MINI ORGAN 13 TONE CODE 243



This mini organ circuit can generate 13 different tones by shorting point P to points A-M, A produces the lowest frequency and M produces the highest.

## **Technical specifications:**

- power supply: 9VDC.
- consumption: 75mA max. (working), 5mA (stand by)
- there are 13 different tones.
- dimensions: 3.72 x 1.04 inches

#### How to works:


IC1 555 timer is used here as a frequency generator. R1 to R13 acts as the frequency adjustment for each tone. The circuit can be connected to any type of speaker but best suited to the included 2 inches 8 ohm 0.25 watts speaker.

#### PCB assembly:

Shown in Figure 3 is the assembled PCB. Starting with the lowest height components first, taking care not to short any tracks or touch the edge connector with solder. Some tracks run under components, and care should be taken not to short out these tracks. If the pins will not enter the holes with ease, use a small drill to slightly enlarge the opening. All components with axial leads should be carefully bent to fit the position on the PCB and then soldered into place. Make sure that the electrolytic capacitors are inserted the correct way around. Some components are particularly sensitive to heat (ie: Transistors, IC's, diodes etc.) extra care must be taken to only apply the iron for as little time as possible, using a pair of pliers to grip the leads will help conduct heat away. Trim components leads with wire cutters to prevent excess lengths causing a short circuit. Now check that you really did mount them all the right way round!


### **Testing:**


This kit has an operating voltage range of 9 VDC. Apply power supply. Short point A to M with point P, you will hear the tone from the loudspeaker which have 13 different tones follow shorting each point.



#### **Troubleshooting:**

The most problem like the fault soldering. Check all the soldering joint suspicious. If you discover the short track or the short soldering joint, re-solder at that point and check other the soldering joint. Check the position of all component on the PCB. See that there are no components missing or inserted in the wrong places. Make sure that all the polarised components have been soldered the right way round.









•			
	CODE FK	DESCRIPTION	POWER
	156	MINI TRAFFIC LIGHT 3 LED	9-12VDC
	157	TWO WAY CHASING LIGHT TWO COLOUR 10 LED	9-12VDC
	158	STROBOSCOPE 220V	220VAC
	159	SHAKING DICE	9-12VDC
	160	RANDOM NUMBER GAME 1 DIGIT	9-12VDC
	273	MUSIC DOOR (WITH MAGNATIC SWITCH)	3VDC
	274	MINI ORGAN 13 TONE (WITH MAGNATIC SWITCH)	9VDC
	325	RINGING SIGNAL LIGHT 5 LED	NONE
	672	MINI MEGAPHONE (WITH SPEAKER)	4.5-12VDC